



# TOYOTA HARNESS

- 1) **Unplug the factory turn signal connector from the main harness.**
- 2) **Remove one wire at a time from the turn signal connector and replace with the same color wire on the new harness.**
- 3) **You will need a small terminal removing tool to help removing the terminals in the connector.**
- 4) **Do the same for the running light connector.**

**Thank you,**

**Gary**

**If you have any questions or need help please email me @**

**[help@innovativewiring.com](mailto:help@innovativewiring.com)**